

90° Offset Heads xture cessor



0 - 4.5

DIATEST Offset Heads deflect travel motion by 90° and have a travel range of 4.5mm or .177 in. Their compact size and standardized companion dimensions make them a useful accessory in fixture building and offer a wide range of application in gauging fixtures and measuring machines; in shape gauges and locating gauges, e.g. to measure roundness, cylinder shape, or spacing; in machine tools, e.g. for dial indicated carriage stop; in fact, in all instances where travel motion has to be deflected.

The uniform connecting thread "X" of M6 x 0.75 ensures that all system parts can be readily joined and interchanged.

-90° Offset Heads

Travel Motion Offset by 90°
Travel Range 4.5 mm or .177 inch
Stem O.D.: 8 mm—0.01 (.31496"—.0004)

Stem Lengths available:

L = 5 mm (.197") 10 mm (.394") 15 mm (.591") 20 mm (.787") 25 mm (.984") 40 mm (1.575") 60 mm (2.362") Transfer Spindle O.D.: 4 mm — 0.01 (.15748" — .0004)

Contact Point Thread "Y": M2.5—6H Other Stem Lengths "L" and other


Contact Point Threads "Y": special, on request

1.1 Offset Head Model UK-L


Length of Transfer Spindle: 5 to 9.5 mm = 4.5 mm travel (.197" to .374" = .177" travel)

Accessory parts clamp to exposed spindle portion.

1.2 Offset Head Model UK-K Length of Transfer Spindle: 0 to 4.5 mm = 4.5 mm travel




- 4.1 Right Angle Attachment Permits "double-bend" (90° 90°) offset Screws onto offset head or extension O.D. 8 mm
- 4.2 Double Clamp I.D. 8 mm (.315") x O.A.L. 20 mm (.787") Securely holds two joined parts, e.g. as in 4.1, and prevents them from twisting in threaded





2 - Dial Gauge Holders Take dial indicators, micro comparators, or electronic probes, having a stem diameter of 8 mm h6, but see NOTE.

- 2.1 Dial Gauge Holder O.D. 10 mm (.394 in.) O.A.L. 51 mm (2.008 in.)
- 2.2 Short Dial Gauge Holder O.A.L. 32 mm (1.26 in.)
- 2.3 Dial Gauge Holders O.D. 10 mm (.394 in.) material temperature stabilized Available O.A.L.: L = 100 mm (3.94") 150 mm (5.9") 200 mm (7.8") 290 mm (11.4")

NOTE-Not Illustrated: Dial Gauge Holder 3/8" O.A.L. 51 mm (2.008") with 3/8" (9.525 mm) collet







3 -Extensions

Transfer travel motion between system parts, e.g. between offset heads and dial gauge holders

3.1 Extensions O.D. 8 mm (.315 in.)

Available Lengths: L = 20 mm (.787") 30 mm (1.181")

40 mm (1.575") 50 mm (1.97")

64 mm (2.52") 125 mm (4.92")

250 mm (9.84") 500 mm (19.68")

750 mm (29.53") 1000 mm (39.37")

Extensions of L = 125 mm and over: material temperature stabilized

Extensions O.D. 8 mm h5 (.31496" - .00024)

Hard chrome plated for use as rotating parts, e.g. in shape or locating gauges Available in $L=64\,\text{mm}\,(2.52^{\prime\prime})$

125 mm (4.92") material temperature stabilized

3.2 Extensiona O.D. 10 mm (.394")

Material temperature stabilized Available in L = 240 mm (9.45") 500 mm (19.68") 750 mm (29.53") 1000 mm (39.37")



5 —Offset Heads Model ZM Deflect travel motion by 90° in confined areas. Useful component in shape, spacing, and locating gauges.

5.1 Model ZM-10


Contact point: solid carbide ball, dia. 2.5 mm (.098")
Dimension "A" = 4.6mm (.181") + travel of 2.5 mm (.098")
Dimension "B" = 14 to 15 mm (.551 to .590") travel dependent

Offset Head Models ZM-13 through ZM-41

Spherical contact tip: solid carbide, radius R = 4 mm (.157")

5.2 Model ZM-13: dim. "A" = 6.1 mm (.240") + travel of 3 mm (.118") Model ZM-17: dim. "A" = 8.1 mm (.319") + travel of 3 mm (.118")

5.3 Model ZM-21: dim. "A" = 10.1 mm (.398") + travel of 3 mm (.118")
Model ZM-25: dim. "A" = 12.1 mm (.476") + travel of 3 mm (.118")
Model ZM-29: dim. "A" = 14.1 mm (.555") + travel of 3 mm (.118")
Model ZM-33: dim. "A" = 16.1 mm (.634") + travel of 4.5 mm (.177")
Model ZM-37: dim. "A" = 18.1 mm (.713") + travel of 4.5 mm (.177")
Model ZM-41: dim. "A" = 20.1 mm (.791") + travel of 4.5 mm (.177")



6 -Gauging Inserts

Threaded M2.5-6g (M2.6 or others: special, on request)

6.1 Contact Point

O.D. 4 mm (.157") x O.A.L. 5 mm (.197") Spherical contact tip: solid carbide, radius R = 8 mm (.315'')

6.2 Ball Contact Points


Spindle O.D. 4 mm (.157") x 5 mm (.197") long Furnished with solid carbide balls ± 0.001 mm (± 000040 "), hardness 1,600 Vickers Available ball diameters: 0.500 0.501 0.502 0.503 etc. to 15.000 mm, in increments of 0.001 mm. Inch sizes also available Other spindle lengths: special, on request.

6.3 Dial Gauge Spindle Extensions O.D. 4 mm (.157")

Available in lengths "L": 10 mm (.394") 20 mm (.787") 30 mm (1.18") to 100 mm (3.94") in increments of 10 mm (.394")

Other spindle lengths: special, on request.

All dimensions in drawings are shown in millimeters. Convert to inches by multiplying by .03937. Thread "X" = M6 x 0.75. Thread "Y" = M2.5—6H.



Ø 16

20

